



MOBILE SCREENING & CRUSHING

PARTS LIST - IN STOCK
Mobile Screening & Crushing Ltd
 0800 MSC LTD (672 583)
 parts@mobilescreening.co.nz
 www.mobilescreening.co.nz

NOTE: these are the parts we stock continuously, we can order in any parts not on this list for your machine

Item Number	Item Name	Machine	Part #
BEARINGS AND HOUSINGS			
BH-207-1.25-Bearing	Bearing UC207 1.25inch	McCloskey Trommel	
BH-207-1.25-Housing	Housings P207 1.25inch	McCloskey Trommel	
BH-SCRNBX-B&H	Screenbox Bearings/Housings Co	Anaconda DF, SR	301-0299
BH-SCRNBX-Bearings	Screenbox Bearings	Anaconda DF, SR	301-0306
BH-SCRNBX-Sleeves	Adaptor Sleeves	Anaconda DF, SR	
BRUSHES			
BR-AN	Anaconda Trommel Brush	Anaconda TD	301-0415
BR-MC	McCloskey Brush	McCloskey Trommel	
BELTS AND SCRAPERS			
BS-001	Collection Conveyor Scraper		
BS-002	Feeder Scraper Assembly		
BS-003	Feeder Conveyor Scraper		
BS-DF512-Feeder Belt	DF512 Feeder Belt	Anaconda DF512	
BS-DF512-Fines belt	DF512 Fines Belt	Anaconda DF512	
BS-DF512-Mids Belt	DF512 Mids Belt chevron	Anaconda DF512	
BS-DF-Coll Conv	DF410 Collection trans Belt	Anaconda DF410	301-0252
BS-DF-Feed Conv	DF410 Feed Conveyor Belt	Anaconda DF410	301-0588
BS-DF-Side Conv - chev	DF410 Mids Belt chevron	Anaconda DF410	301-0590
BS-DF-Side Conv - plain	DF410 Fines Belt side convy pl	Anaconda DF410	301-0589
FILTERS			
F-CAT-4.4-Air inner	CAT 4.4 - Inner Air Filter		301-0871
F-CAT-4.4-Air outer	CAT 4.4 - Outer Air Filter		
F-CAT-4.4-Element Ass	CAT 4.4 - Element Assembly		
F-CAT-4.4-Fuel Filter	CAT 4.4 - Fuel Filter		
F-CAT-4.4-Oil	CAT 4.4 - Oil Filter		
F-CAT-Air inner 2.2	CAT Inner Air Filter 2.2	McCloskey Machines	
F-CAT-Air outer 2.2	CAT Outer Air Filter 2.2	McCloskey Machines	
F-CAT-Element Ass 2.2	CAT Element Assembly 2.2	McCloskey Machines	
F-CAT-Fuel / water sep 2.2	CAT Fuel / Water Separator 2.2	McCloskey Machines	
F-CAT-Oil 2.2	CAT Oil Filter 2.2		
F-DTZ Fuel Filter	DTZ Fuel Filter		
F-DTZ Inner Air	DTZ Inner Air Filter		
F-DTZ Outer Air	DTZ Outer Air Filter		
F-DTZ-Filter Ass	DTZ Filter Assembly		
F-DTZ-Fuel sieve	DTZ Fuel Sieve		
F-DTZ-Fuel/Water separator	DTZ Fuel Water separator		
F-DTZ-Oil	DTZ Oil Filter		
F-JCB Engine Pack	JCB Engine Pack		
F-JCB-Air inner	JCB Inner Air Filter		
F-JCB-Air outer	JCB Outer Air Filter		
F-JCB-Element Ass	JCB Element Assembly		301-0402
F-JCB-Fuel	JCB Fuel Filter		301-0401
F-JCB-Oil	JCB Oil Filter		301-0400
GENERAL - ANACONDA			
GA-001	Emergency Stop	Anaconda DF, SR, TD	301-0597
GA-002	Beacon	Anaconda DF, SR, TD	301-0241
GA-003	Siren	Anaconda DF, SR, TD	301-0239
GA-004	Door Latch T Handle	Anaconda DF, SR, TD	301-0379

Item Number	Item Name	Machine	Part #
GA-005	Southco Control Panel Door Lat	Anaconda DF, SR, TD	301-0244
GA-006	Fuel Cap	Anaconda DF, SR, TD	301-0140
GA-007	Filler Cap	Anaconda DF, SR, TD	301-0009
GA-008	Donaldson Check Valve	Anaconda JCB	301-0720
GA-009	Spare Keys for all machines	Anaconda	
GA-010	Dog Lead	Anaconda	
GA-011	Dog Lead Plug	Anaconda	
GA-012	Track Links (old style)	Anaconda	301-1255
GA-013	Throttle Cable	Anaconda	
GA-014	Silicone Hoses	Anaconda	
GA-015	Screen Shaft	Anaconda	
GA-016	Taper lock 40mm	Anaconda	
GA-017	TD516 Spiked Feed	Anaconda	
GA-018	Screenbox tension block	Anaconda	301-0322
GA-019	Motor Coupling Screen Box	Anaconda	
GA-020	Screenbox Spring DF410	Anaconda	301-0312
GA-021	Drum Drive Wheels TD516	Anaconda	301-0406
GA-022	Feeder Headrum Assembly	Anaconda	
GA-024	Couplings 2.5 inch	Anaconda	
GA-025	Drum Hardware Kit	Anaconda	
GA-028	JCB Fan Belt	Anaconda	
GA-029	Drum Retaining Wheel	Anaconda	301-0428
GA-030	Drum Retaining Wheel Pin	Anaconda	104-0733
GA-031	Ball knob for hydraulic valve	Anaconda	
GA-032	Wear Pad 2 hole	Anaconda	301-0416
GA-033	Wear Pad 4 hole	Anaconda	301-0417
GA-31	Retaining Wheel Bearing	Anaconda	
GA-32	Throttle Cable JCB	Anaconda	
GA-34	Water level sensors	Anaconda	20.00.1025
GENERAL - MCCLOSKEY			
GM-001	MC516 RTE Throttle Cable	McCloskey	
GA035	MC516 Drum Wheel	McCloskey	
HYDRAULIC			
H-CV111-Seal	Control Valve Seal CV111	Anaconda DF, TD, SR	401-0002
H-CV112-Seal	Control Valve Seal CV112	Anaconda DF, TD, SR	401-0003
H-CV113-Seal	Control Valve Seal CV113	Anaconda DF, TD, SR	401-0004
H-CV601-Control Valve	Hydraulic Control Valve CV601,	Anaconda DF, TD, SR	
H-CV601-Seal	Control Valve Seal CV601	Anaconda DF, TD, SR	401-0005
H-CV691-Control Valve	Hydraulic Control Valve CV691,	Anaconda DF, TD, SR	
H-CV691-Seal	Control Valve Seal CV691	Anaconda DF, TD, SR	401-0007
H-CV791-Control Valve	Hydraulic Control Valve CV791,	Anaconda DF, TD, SR	
H-CV791-Seal	Control Valve Seal CV791	Anaconda DF, TD, SR	401-0006
H-DTZ-Triple Pump	Triple Pump - Deutz	Anaconda DF Fig 12, SR	
H-Filter Element toptank DF410	Filter Element toptank DF410		301-0342
H-Filter Element toptank DF512	Filter Element toptank DF512		301-1334
H-Filter Suction Element	Filter Suction Element SE1323	Anaconda DF Fig 13, SR, TD	301-0349
H-OMT Motor	OMT Motor	Anaconda DF, TD Fig 21, SR	
H-RAM ARM	Ram Arm		
H-RAMS-over	Rams Oversize		
H-RAMS-side	RAMS side conveyor		
H-Rear Seal Kit-4000	Rear Seal Kit 4000 series No.	Anaconda DF, TD, SR	
H-Rear Seal Kit-6000	Rear Seal Kit 6000 series No.	Anaconda DF, TD, SR	
H-SCRNBX Motor Seal Kit	Screenbox motor seal kit		
H-Shaft End Kit-4000	Shaft End Kit 4000 series No.	Anaconda DF, TD, SR	
H-Shaft End Kit-6000	Shaft End Kit OMV630 6000 seri	Anaconda DF, TD, SR	
H-Shaft Seal Kit-2000	Shaft Seal Kit 2000 series No.	Anaconda DF, TD, SR	
H-Suction Cups	Suction Cups		

Item Number	Item Name	Machine	Part #
MESHES			
M-DF410-BD10mm	DF410 5 x 4 BD mesh 10mm	Anaconda DF410	
M-DF410-BD12mm flexi	DF410 BD mesh 12mm - flexi	Anaconda DF410	
M-DF410-BD15mm	DF410 5 x 4 BD mesh 15mm	Anaconda DF410	
M-DF410-BD20mm	DF410 5 x 4 BD mesh 20mm	Anaconda DF410	
M-DF410-BD20mm flexi	DF410 5 x 4 BD mesh 20mm - fle	Anaconda DF410	
M-DF410-BD23mm	DF410 5 x 4 BD mesh 23mm	Anaconda DF410	
M-DF410-BD25mm	DF410 5 x 4 BD mesh 25mm	Anaconda DF410	
M-DF410-BD30mm	DF410 5 x 4 BD mesh 30mm	Anaconda DF410	
M-DF410-BD40mm	DF410 5 x 4 BD mesh 40mm	Anaconda DF410	
M-DF410-BD60mm	DF410 5 x 4 BD mesh 60mm	Anaconda DF410	
M-DF410-BD65mm	DF410 5 x 4 BD mesh 65mm	Anaconda DF410	
M-DF410-BD7mm flexi	DF410 5 x 4 BD mesh 7mm - flex	Anaconda DF410	
M-DF410-BD8mm flexi	DF410 5 x 4 BD mesh 8mm - flex	Anaconda DF410	
M-DF410-TD100mm pnch(1of3)	DF410 TD 100mm - punch (1of3)	Anaconda DF410	
M-DF410-TD150mm pnch(1of3)	DF410 TD 150mm - punch (1of3)	Anaconda DF410	
M-DF410-TD20mm	DF410 10 x 4 TD mesh 20mm	Anaconda DF410	
M-DF410-TD25mm flexi	DF410 10 x 4 TD 25mm - flexmat	Anaconda DF410	
M-DF410-TD40mm	DF410 TD mesh 40mm old style	Anaconda DF410	
M-DF410 TD 40mm (1of3)	DF410 TD Mesh 40mm	Anaconda DF410	
M-DF410-TD65mm old	DF410 TD 65mm mesh old	Anaconda DF410	
M-DF410-TD65mm pnch old s	DF410 TD 65mm - punch old styl	Anaconda DF410	
M-DF410-TD75mm pnch old s	DF410 TD 75mm - punch old styl	Anaconda DF410	
M-DF410-TD80mm	DF410 TD 80mm old style	Anaconda DF410	
M-DF512 TD200mm punch (1of3)	DF512 TD 200mm punch (1of3)	Anaconda DF512	
M-DF512-BD20mm	DF512 BD 20mm	Anaconda DF512	
M-DF512-BD40mm	DF512 BD 40mm	Anaconda DF512	
M-DF512-BD65mm	DF512 BD 65mm	Anaconda DF512	
M-DF512-TD100mm punch (1of3)	DF512 TD 100mm punch (1of3)	Anaconda DF512	
M-DF512-TD150mm punch (1of3)	DF512 TD 150mm punch (1of3)	Anaconda DF512	
M-DF512-TD175mm punch (1of3)	DF512 TD 175mm punch (1of3)	Anaconda DF512	
M-DF512-TD20mm (1of3)	DF512 TD 20mm (1of3)	Anaconda DF512	
M-DF512-TD20mm punch (1of3)	DF512 TD 20mm punch (1of3)	Anaconda DF512	
M-DF512-TD40mm (1of3)	DF512 TD 40mm (1of3)	Anaconda DF512	
M-DF512-TD65mm (1of3)	DF512 TD 65mm (1of3)	Anaconda DF512	
M-DF-Bofer Bars 100mm	DF Bofer bars (full set) 100mm	Anaconda DF410	
M-TD516-12mm (1of3)	TD16 Mesh 12mm (1of3)	Anaconda TD516	
M-TD516-14mm (1of3)	TD516 mesh 14mm (1of3)	Anaconda TD516	
M-TD516-20mm (1of3)	TD516 mesh 20mm (1of3)	Anaconda TD516	
M-TD516-3mm (1of3)	TD516 mesh 3mm (1of3)	Anaconda TD516	
M-TD516-4mm (1of3)	TD516 Mesh 4mm (1of3)	Anaconda TD516	
M-TD516-4mm sq (1of3)	TD16 Mesh 4mm sq (1of3)	Anaconda TD516	
M-TD516-6mm (1of3)	TD516 Mesh 6mm (1of3)	Anaconda TD516	
M-TD516-8mm	TD516 Mesh 8mm 1of3	Anaconda TD516	
PIANO WIRES			
PW-DF410-10mm	Piano wire DF410 - 5x4 10mm	Anaconda DF410	
PW-DF410-10mm used	Piano Wire DF410 - 10mm used	Anaconda DF410	
PW-DF410-12mm	Piano wire DF410 - 5x4 12mm	Anaconda DF410	
PW-DF410-14mm	Piano wire DF410 - 5x4 14mm	Anaconda DF410	
PW-DF410-14mm used	Piano wire DF410 - 5x4 14mm us	Anaconda DF410	
PW-DF410-16mm	Piano wire DF410 - 5x4 16mm	Anaconda DF410	
PW-DF410-1mm used	Piano wire DF410 - 5x4 1mm use	Anaconda DF410	
PW-DF410-3mm	Piano wire DF410 - 5x4 3mm	Anaconda DF410	
PW-DF410-3mm used	Piano Wire DF410 - 3mm used	Anaconda DF410	
PW-DF410-6mm	Piano wire DF410 - 5x4 6mm	Anaconda DF410	
PW-DF410-6mm used	Piano wire DF410 - 5x4 6mm use	Anaconda DF410	
PW-DF410-8mm	Piano wire DF410 - 5x4 8mm	Anaconda DF410	

Item Number	Item Name	Machine	Part #
PW-DF512-12mm	Piano Wire DF512 -12mm	Anaconda DF512	
PW-DF512-16mm	Piano Wire DF512 - 16mm	Anaconda DF513	
PW-DF512-3mm	Piano Wire DF512 - 3mm	Anaconda DF514	
PW-DF512-6mm	Piano Wire DF512 6mm	Anaconda DF515	
PW-DF512-8mm	Piano wire DF512 - 5x4 8mm	Anaconda DF516	
RUBBER			
RB-ALL-SKT-10Lx120Hx10W	Skirting Rubber 120mm		301-1336
RB-ALL-SKT-10Lx70Hx10W	Skirting Rubber 70mm		301-1337
RB-ALL-SKT-5Lx90Hx10W	Skirting Rubber 90mm		301-1338
RB-DF-FEEDBT-fines conveyor	Feedboot Fines Conveyor	Anaconda DF, Fig 8	
RB-DF-FEEDBT-mids conveyor	Feedboot Mids conveyor	Anaconda DF, Fig 8	
RB-DF-FEEDBT-oversize conveyor	Feedboot Oversize conveyor	Anaconda DF, Fig 6	
RB-DF-SCRNBX Capping Rubber	Capping Rubber	Anaconda DF, SR	301-1339
RB-DF-SCRNBX-clamp seal	Screenbox clamp seal	Anaconda DF	
RB-DF-SCRNBX-rear	Screenbox rubber rear	Anaconda DF, Fig 11 - R or L	
RB-DF-SCRNBX-side	Screenbox rubber side	Anaconda DF, Fig 11	
RB-DF-SCRNBX-TD end chute	Screenbox topdeck end chute	Anaconda DF, Fig11	
RB-DF-SCRNBX-tension	DF410 Screenbox Tension Bar		
RB-DF-SKT-20mm Roll	Feeder Skirting Rubber Roll 20	Anaconda DF	
RB-DF-SKT-5x100x12	Skirting Rubber - DF 5m x 100m		
RB-DF-SKT-Collection Conveyor	Skirting Rubber for Collection	Anaconda DF, Fig 5	
RB-DF-SKT-Feeder Drum	Feeder Drum Skirting Rubber	Anaconda DF, Fig 3	
RB-DF-SKT-feeder rear	Skirting Rubber (Rear) Feeder		
RB-DF-SKT-headrum	DF410 Skirting rubber headrum		
RB-DF-SKT-rear	DF410 Skirting Rubber - rear		
RB-DF-SKT-side	DF410 Skirting Rubber - side		
RB-SR-FEEDBT-side conveyor mid	Side Conveyor Feedboot Rubber	Anaconda SR, Fig 13	
RB-SR-FEEDBT-side conveyor ovr	Side Conveyor Feedboot Overs		
RB-SR-FEEDBT-tail conveyor	Tail Conveyor Feedboot	Anaconda SR, Fig 11	
RB-SR-SCRNBX-bottom lip	Screenbox Bottom Lip Rubber	Anaconda SR, Fig 8	
RB-SR-SCRNBX-bottom lip top	Screenbox bottom Lip Rubber To	Anaconda SR, Fig 8	
RB-SR-SCRNBX-rear1	Screenbox Rubber Rear	Anaconda SR, Fig 8	
RB-SR-SCRNBX-rear2	Screenbox Rubber Rear	Anaconda SR, Fig 8	
RB-SR-SCRNBX-side	Screenbox Rubber Side	Anaconda SR, Fig 8	
RB-TD-bin sealing	Bin Sealing Rubber	Anaconda TD, Figure 3	
RB-TD-collection sealing	Collection Sealing Rubber	Anaconda TD, Figure 3	
RB-TD-Drum seal	Drum Seal Screen Rubber	Anaconda TD	
RB-TD-feeder scraper	Feeder Scraper Rubber	Anaconda TD, Figure 9	
RB-TD-outlet chute	Outlet Chute Rubber	Anaconda TD, Figure 3	
RB-TD-SKT-collection	Collection Skirting Rubber	Anaconda TD, Figure 3	
RB-TD-SKT-Feeder Drum new	Feeder drum skirting Rubber ne	Anaconda TD, Figure 9	
RB-TD-SKT-Feeder Drum old	Feeder drum skirting Rubber ol	Anaconda TD, Figure 9	
RB-TD-SKT-feeder side	Feeder Skirting Rubber Side	Anaconda TD, Figure 8	
RB-TD-SKT-Fines Conv Rear	Fines Conveyor Skirting - rear	Anaconda TD, Figure 19	
RB-TD-SKT-Fines conv side	Fines Conveyor Skirting - side	Anaconda TD, Figure 19	
ROLLERS			
RL-CENTR-L314	L314 Centre Roller	Anaconda all machines	301-0100
RL-CENTR-L388	L388 Centre Roller	Anaconda all machines	301-0101
RL-CENTR-L490	L490 Centre Roller	Anaconda all machines	301-0102
RL-CENTR-L648	L648 Centre Roller	Anaconda all machines	301-0108
RL-CENTR-L688	L688 Centre Roller	Anaconda all machines	301-0036
RL-DISC-RT-L1169	L1169 Disc Return Roller	Anaconda all machines	301-0105
RL-DISC-RT-L1280	L1280 Disc Return Roller	Anaconda all machines	301-0043
RL-DISC-RT-L919	L919 Disc Return Roller	Anaconda all machines	
RL-FTR-High Impact	FTR High Impact Rollers	Anaconda all machines	301-0267
RL-Guide-D120	D120 Guide Roller (Feeder)	Anaconda all machines	301-0255
RL-Impact Bar-1260	1260 Impact Bars	Anaconda all machines	301-0263

Item Number	Item Name	Machine	Part #
RL-PLAIN-RT-L919	L919 Plain Return Roller	Anaconda all machines	301-0501
RL-Tail Conveyor WP - L	Tail Conveyor Wear Plate - lef	Anaconda all machines	
RL-Tail Conveyor WP - R	Tail Conveyor Wear Plate - rig	Anaconda all machines	
RL-Thumper/Beater	Beater or Thumper Roller for o	Anaconda all machines	
RL-WING-20d Long L	20d Long Left Wing Roller	Anaconda all machines	301-0071
RL-WING-20d Long R	20d Long Right Wing Roller	Anaconda all machines	301-0070
RL-WING-20d Short L	20d Short Left Wing Roller	Anaconda all machines	301-0124
RL-WING-20d Short R	20d Short Right Wing Roller	Anaconda all machines	301-0123
RL-WING-30d Long L	30d Long Left Wing Roller	Anaconda all machines	301-0035
RL-WING-30d Long R	30d Long Right Wing Roller	Anaconda all machines	301-0034
RL-WING-30d Short L	30d Short Left Wing Roller	Anaconda all machines	301-0075
RL-WING-30d Short R	30d Short Right Wing Roller	Anaconda all machines	301-0074
RL-WING-45d Long L	45d Long Left Wing Roller	Anaconda all machines	301-0033
RL-WING-45d Long R	45d Long Right Wing Roller	Anaconda all machines	301-0032
RL-WING-45d Short L	45d Short Left Wing Roller	Anaconda all machines	301-0072
RL-WING-45d Short R	45d Short Right Wing Roller	Anaconda all machines	301-0073